9 Wiring Diagram

50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
-	-	-	GND	GND	5V+PANEL	5V+PANEL	5V+PANEL	5V+PANEL	GND	DHS	DVS	GND	DEN	GND	DCK	GND	R_OUT(7)	R_OUT(6)	R_OUT(5)	R_OUT(4)	GND	R_OUT(3)	R_OUT(2)	R_OUT(1)	R_OUT(0)	GND	G_OUT(7)	G_OUT(6)	G_OUT(5)	G_OUT(4)	GND	G_OUT(3)	G_OUT(2)	G_OUT(1)	G_OUT(0)	GND	B_OUT(7)	B_OUT(6)	B_OUT(5)	B_OUT(4)	GND	B_OUT(3)	B_OUT(2)	B_OUT(1)	B_OUT(0)	GND	GND	-	-

CN702 (LW20M21C ONLY)

1	SW_Inverter
2	GND
3	5V
4	5V
5	-
6	GND
7	GND
8	14V
9	14V

CN100

30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
OUT19	OUT18	OUT17	OUT16	OUT15	OUT14	GND	OUT13	OUT12	GND	Video In	Video Out	GND	GND	BL In	Cr	GND	GND	NC	Y	NC	GND	ID	GND	-	-	-	5V	5V	5V

CN700 (LW17M24C ONLY)

1	LED-GRN
2	LED-RED
3	-
4	3.3V
5	IR
6	GND
7	IDENT_HP
8	HP-L
9	HP-R
10	GND
11	KEY 1
12	KEY 2
13	GND
14	GND

CN907

4	GND
5	PC_AR
6	PC_AL
7	PC_AL
8	PC_AL
9	PC_AR
10	PC_AR

CN909

CN908

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
PC_SCL	D SUB_V	D SUB_H	PC_SDA	GND	IDENT_PC	DC_5V	GND	GND	GND	GND	GND	PC_Blue	PC_Green	PC_Red

CN900

3	2	1
Video-CVBS	Video-CVBS	GND

U1913

6	5	4	3	2	1
Audio-L	Audio-L	GND	Audio-R	Audio-R	GND

CN903

6	5	4	3	2	1
-	GND	GND	GND	S_Video_Y	S_Video_C

CN902

21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
GND	Video In	Video Out	GND	GND	BL In	Cr	GND	GND	NC	Y	NC	GND	ID	Cb	Sound L In	GND	GND	Sound L out	Sound R In	Sound R out

CN600

5	4	3	2	1
GND	GND	OUT-L	-	OUT-L

CN601

4	3	2	1
GND	GND	OUT-R	OUT-R

Memo